


# **QUICK START GUIDE**

#### WHAT'S INSIDE

- A Vacuum Pod
- B Motorized Floor Nozzle
- C Handle & Hose
- Wand


- Accessory Holder
- 12" Crevice Tool
- G Upholstery Tool


#### **ASSEMBLY**



NOTE: For proper operation, ensure all parts are firmly CLICKED into place.

#### TWO WAYS TO CLEAN






Attach accessories to handle or wand.

For additional parts and accessories, visit sharkaccessories.com

#### **EMPTYING THE DUST CUP**

#### TIPS

#### Empty the dust cup after each use.



MAINTENANCE: Rinse pre-motor filters every 3 months, and HEPA filter once a year. Rinse with water only, and allow to air-dry completely before reinstalling.

See enclosed Owner's Guide for more information on how to clean and replace the filters.



For quick cord access, rotate upper hook down and remove cord.




Move cord hook to upright position to secure cord in place.



To store your vacuum, wrap cord around upper and lower hooks.

### **CHECKING FOR BLOCKAGES**


If any hair is wrapped around brushroll, extending cleaning time will help it clear.



#### **Brushroll access**



#### Clear Airway



Using a coin, turn locks counterclockwise to open, then lift off cover to access brushroll. Clear blockages from airway.

Replace cover, pressing down firmly on all sides before turning locks clockwise to close.



## Zero-M™ Cleaner Head

The Shark Zero-M self-cleaning brushroll delivers nonstop hair removal. Check for blockages or objects stuck in the brushroll.





