

Shark

DETECT PRO™

SELF-EMPTY ROBOT


QUICK START GUIDE

RV2800S Series

Getting Started


1 Set up Self-Empty Base

- Remove any plastic wrap and foam from the robot and base.
- Place base in a location with a strong Wi-Fi signal.
- Dock LED will turn green when powered ON.
- **Note:** Check between the bumper and wheels to ensure all protective materials are removed prior to robot use.




2 Attach Side Brush

- **Note:** Side brush design may vary.



3 Place Robot on Self-Empty Base

- Robot will turn on when properly placed on the dock.
- Dock LED will turn blue when the robot is charging.



4 Scan QR code to download the SharkClean® app to complete robot setup.



App Features


- ✓ Mapping
- ✓ Scheduling
- ✓ No-Go Zones
- ✓ Cleaning Reports



Turn Page 

What's Included

Robot




Shark® Detect Pro™ Robot.

Side Brush



Moves debris into robot's path.

Self-Empty Base



Holds dirt and debris.
Capacity varies based on model.

Tips and Tricks

- To manually turn ON/OFF your robot, hold down the DOCK button for 5-7 seconds.
- When performing maintenance, always place the robot on a level surface and turn off the power.
- Clean brushroll and filter regularly.


Customer Support

1. Visit: sharkclean.com/support
 - Owner's Guide
 - Troubleshooting
 - How-To Videos
 - FAQs
 - Tips & Tricks
2. For additional help, please scan the QR code to visit the digital support site or call **1-888-228-5531** for robot support.



Maximize Your Robot Experience

- **DirtDetect**
When the robot detects a mess, the lights will turn purple and show how much debris is being picked up in real time as it engages in a deep cleaning pattern.



- **Shark NeverStuck™ Technology**
Your robot will adjust its suspension and the orange lights will illuminate when the robot moves over obstacles.

