
# Shark. POWERDETECT


NEVERTOUCH™ 2-IN-1


**VACUUM, MOP, SELF-EMPTY, & SELF-REFILL** 


## **WHAT'S INCLUDED:**

- **1.** Robot (1X)
- 2. NeverTouch™ Base (1X)
- **3.** Ramp (1X)
- 4. Side Brush (2X)
- **5.** Mopping Pads (quantity varies)
- **6.** Shark® Multi-Surface Cleaner 12 oz. (355 mL) Bottle (1X)















# **SETTING UP YOUR ROBOT**

Remove all parts and accessories from the box before starting the following setup steps.


### **Set Up Base**



**Note:** Do not set-up the base on or within 2 feet of a carpeted surface.


- **1.** Remove all plastic wrap and foam.
- 2. Place the base on a flat, level hard-floor surface in a location with strong Wi-Fi signal, with two feet of clearance in front and one foot on either side.
- **3.** Ensure the base is not placed in area with direct sunlight.
- **4.** Plug in the base. The LED will turn green when it is powered on.

### Install Ramp on Base




- **1.** Align the flat side of the ramp with the bottom of the base.
- 2. Lift the ramp slightly above the base, align, and press down until the ramp clicks into place.
- **3.** Leave at least 2 ft. of hard floor space in front of the base, starting from the end of the ramp.

### Fill the Clean Water Tank



- 1. Lift the water tank off the front of the base.
- 2. Add 12 oz. of cleaning solution. Fill the rest of the tank with room-temperature water up to the MAX fill line, then reinstall the tank.


### **Attach a Side Brush to Bottom of Robot**



**Note:** Side brush design may vary. Some models include a spare.

- 1. The side brush can be found inside the robot
- 2. Align the hole in the brush over the peg on the bottom of the robot, then press down on the brush until it clicks into place.

### Slide Robot Onto Base



- 1. Align the robot with the Shark logo upside down, then slide it up the ramp, onto the base.
- **2.** The LEDs on the base will turn green when the robot is charging.
- **3.** After 10 to 15 seconds, the robot will begin to evacuate dust and debris into the base.

# or press the Dry icon □ on your robot to start a dry clean.



### **App Features**

- Mapping
- ✓ Scheduling
- ✓ No-Go Zones
- Cleaning Reports





### FOR FURTHER ASSISTANCE, PLEASE CALL OUR DEDICATED TEAM AT +1-888-668-9600.

© 2024 SharkNinja Operating LLC. SHARK is a registered trademark of SharkNinja Operating LLC. NEVERTOUCH, POWERDETECT, and SHARKCLEAN are trademarks of SharkNinja Operating LLC. APPLE and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. APP STORE is a service mark of Apple Inc. registered in the U.S. and other countries. GOOGLE ASSISTANT, GOOGLE PLAY, the Google Play logo, and Android are trademarks of GOOGLE LLC. RV2800ZE\_PKG\_INSRT\_QSG\_E\_REV\_Mv2