

Please be sure to read the enclosed Shark® Owner's Guide prior to using your vacuum.


# Shark® Rocket®

Hand Vac

## QUICK START GUIDE

### WHAT'S INSIDE

- A** Handheld Vacuum
- B** 12" Crevice Tool
- C** Wide Upholstery Tool
- D** Dusting Brush
- E** Precision Duster
- F** Flexible Hose
- G** Accessory Bag



### ASSEMBLY




#### OPTION 1

Attach flexible hose to handheld vacuum. Attach desired cleaning accessory.

#### OPTION 2

Attach desired cleaning accessory to handheld vacuum.




### MAINTENANCE

**IMPORTANT:** Clean the dust screen inside the dust cup as required.


**NOTE:** Empty dust cup when debris reaches the MAX fill line.

**CHECKING FOR BLOCKAGES:** Check all dust cup intake openings.




#### EMPTYING THE DUST CUP

- 1** Position the handheld vacuum so the dust cup is over a trash bin and press the EMPTY button on the front. The bottom lid will open, allowing the debris to fall out.
- 2** Once dust cup is empty, close the bottom lid.



### SETTINGS



This is the off setting. Slide the Power switch up to turn the vacuum on and begin cleaning.

Visit us online at [sharkclean.com](http://sharkclean.com)



@sharkcleaning