
# **Shark** Navigator

# **QUICK START GUIDE**


# WHAT'S INSIDE

- A Handle
- B Wand
- Hose Dust Cup
- Hose Connector
- Vacuum Body
  - **G** Accessory Holder
  - Floor Nozzle
  - Duster Crevice Tool
  - Upholstery Tool

# **ASSEMBLY**



# TIPS





For quick cord access, rotate upper hook down and remove cord.

To store your vacuum, wrap cord around cord hooks.


# **EMPTYING THE DUST CUP**

Dust cup Release Button



Empty the dust cup after each use.

FILTER MAINTENANCE: Rinse pre-motor filters every month, and the HEPA filter once a year. Rinse filters only with water and air-dry completely before reinstalling.



# **CHECKING FOR BLOCKAGES**



#### **Dust Cup Air Duct:**

Remove and empty dust cup. Check the airway behind dust cup and clear any blockages.







#### **Hose Intake Opening:**

Pull down the hose intake door to remove. Turn the knob on the hose intake to the center, then detach. Clear any obstructions. Reattach the hose intake, then turn the knob to the left to lock. Reinstall the door, clicking it into place.



#### Hose

Disconnect both ends of the hose by gently pressing the tabs together and pulling the hose out of the connectors. Remove any obstructions, then reattach.

# **2 WAYS TO CLEAN**


# **UPRIGHT**

#### Carpet


To use the brushroll to clean carpets, press the Brushroll button and tilt the handle back. The brushroll indicator light will turn green.

#### **Bare Floors**

To clean bare floors or to use the hose, turn off the Brushroll button. The brushroll indicator light will go out.



### **ABOVE-FLOOR CLEANING**



Attach accessories to handle or wand.



For questions or to register your product, visit us online at sharkclean.com







