Shark® Navigator™ LIFT-AWAY®

QUICK START GUIDE

WHAT'S INSIDE

A Vacuum Pod
B Motorized Floor Nozzle
C Handle & Hose
D Wand
E Accessory Holder

F Pet Multi-Tool
G Duster Crevice Tool
H Wide Upholstery Tool
I Precision Duster
J 16" Extension Wand

ASSEMBLY

(Click)

C

Attach your desired accessory

D

(Click)

F   G

A

(Click)

H

(Click)

E

I   J

(Click)

B

NOTE: For proper operation, ensure all parts are firmly CLICKED into place.

TIPS

For quick cord access, rotate upper hook down and remove cord.

Use cord clip to secure cord while in use.

To store your vacuum, wrap cord around cord hooks.

EMPTYING THE DUST CUP

Empty the dust cup after each use.

release

empty

clean

MAINTENANCE: Rinse pre-motor filters every 3 months and HEPA filter once a year. Rinse with water only. Allow filters to air-dry completely before reinstalling.

See enclosed Owner's Guide for more information on how to clean and replace the filters.

CHECKING FOR BLOCKAGES

Brushroll access

Unlock   Open Cover   Clear Intake

Use a coin to turn locks, then rotate cover open.

Clean off any debris on bristles, and clear the debris intake.

With Zero-M™ technology, the brushroll actively removes hair wrap while you vacuum, sending it to the dust cup. Check for blockages or objects stuck in the brushroll.

If any hair is wrapped around brushroll, extending cleaning time will help it clear.

UPRIGHT

O Off
I Hard Floor
II Carpet

Power/Surface switch
Press switch to select surface
setting or to turn off power.
To engage brushroll, step on floor
nozzle and tilt handle back.

LIFT-AWAY®

Handle Release

Press release buttons
to lift pod off nozzle,
or to release handle
or wand.

Suction Control

MAX   MIN

Slide to MIN to increase
maneuverability
on carpets.

Wand Release

Lift-Away Release

Attach accessories to handle or wand.

**For additional parts
and accessories,
visit sharkaccessories.com**