


MAINTENANCE

Empty dust cup after each use




TIP:

Wash filters every 3 months to keep the suction strong. See Owner's Guide for instructions.

Easy brushroll access

To open garage, slide back both access buttons, then lift off garage lid. Lift out Soft Roller by the PULL tab. Clear debris from Soft Roller and brushroll.



To close, insert the tabs on the lid into the slots, then press down on both sides of the lid until it clicks into place. Both sides must be completely closed for vacuum to operate properly.

Shark

To register your product, or for answers to frequently asked questions, visit registryourshark.com.



@sharkcleaning

Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

Shark®

LIFT-AWAY SPEED™

NV770


QUICK START GUIDE

Use this Quick Start Guide
to learn about your new
vacuum's great features.




WHAT'S INSIDE:

- A** Vacuum Pod
- B** Motorized Floor Nozzle
- C** Handle & Hose
- D** Wand
- E** Pet Multi-Tool
- F** Crevice Tool



Attach onboard accessories




For complete maintenance instructions, see the enclosed **Owner's Guide**.

For additional parts and accessories, visit sharkaccessories.com

ASSEMBLY

1. Attach vacuum pod to floor nozzle.
2. Insert wand into pod.
3. Insert handle and hose into wand.
4. Press hose into back of pod.



2 WAYS TO CLEAN:

1


UPRIGHT

Power

Press the Power/Surface Selector button to turn the vacuum on or off.

Floor Setting

Slide the Power/Surface Selector button up or down to choose floor type.



2

LIFT-AWAY

