
Shark ULTRALIGHT PET CORDED STICK VACUUM

QUICK START GUIDE

WHAT'S INSIDE

- A Handheld Vacuum
- Wand
- Floor Nozzle
- Onboard Storage Clip
- - Pet Crevice Tool Upholstery Tool
 - G Precision Duster

ASSEMBLY



NOTE: For proper operation, ensure all parts are firmly CLICKED into place.

TIPS




When storing, wrap cord around cord hooks. For quick cord access. rotate upper hook down and remove cord.



For compact storage, hang the handheld vacuum from the storage hook on the wand.

EMPTYING THE DUST CUP

Empty the dust cup after each use.




RAINTENANCE:
Rinse pre-motor filters
once a month and
post-motor filter once
every 9 months. Rinse
with cold water only.
Allow filters to air-dry
completely before
reinstalling.

FLOOR NOZZLE MAINTENANCE

Debris Intake Access

Check the debris intake and clear away any dirt or blockages. To close the debris intake, press down on each side until it clicks into place.




Brushroll

Remove any debris or hair wrap carefully with your hands or scissors.

VERSATILE FLOOR-TO-CEILING CLEANING


FLOOR MODE

To clean bare floors and carpets, step on floor nozzle and tilt handheld vacuum back. Press the power button to turn on the vacuum and slide the selector switch to toggle between bare floor and carpet cleaning.




ABOVE-FLOOR HANDHELD

Press the release button to detach the handheld vacuum from the wand for precision cleaning. The tapered tip is great for cleaning furniture and countertops.




ABOVE-FLOOR WITH WAND

For more reach, detach the wand. Press the release button on the front of the nozzle neck, and pull the wand to detach.



STAIR CLEANING

To clean stairs or other narrow spaces, attach the handheld vacuum to the floor nozzle.



For additional parts and accessories, visit sharkaccessories.com





